



Digipass 270 User manual (two-factor authentication)

Getting started

To start using Digipass (hereinafter referred to as the device), press  and, holding it, press .

Turning the device on for the first time, you will be prompted to enter the initial PIN-code provided by the bank.

1. After the initial PIN-code is entered, the prompt for entering the new PIN-code will be displayed: **NEW PIN**. The new PIN-code should consist of 4 digits. Enter the new PIN-code twice.

2. If the PIN-code is re-entered correctly, the following message will be displayed: **NEW PIN CONF**.

3. Memorize the new PIN-code to be further used.

To change the PIN-code, after the device is activated and APPLI- is displayed, press  and hold it until **NEW PIN** is displayed. Follow the instructions in paragraphs 1–3 above.

Logging in to the Internetbank

To log in to the Internetbank, after the device is activated and APPLI- is displayed, press **"1"**.

The obtained value (8 digits) can be used to log in to the Internetbank only once.

Signing of documents

To sign the documents and confirm the actions in Internetbank, after the device is activated and APPLI- is displayed, press **"1"**.

The obtained value (8 digits) can be used to sign the documents or confirm the actions only once.

Unblocking of the device

If incorrect PIN-code is entered, the following message will be displayed: **PIN FAIL 1**. The digit stands for the number of incorrect PIN-code entries.

The error message will be also displayed after the device is turned off and on again. To enter the PIN-code once again, press .

After five successive entries of incorrect PIN-code, the device will be blocked. The following message will be displayed:

LOCK PIN FAIL 5.

To unblock the device, call Client Line at **+371 6777 5555** or your private banker.

If your Digipass is lost,
immediately inform the bank
by calling at **+371 6777 5555** or
contacting your private banker.



ABLV